


## EXPLOSIVE VIEW OF WD041710180



**PART LIST OF WD041710180**

<b>NO</b>	<b>DESCRIPTION</b>	<b>Q'TY</b>	<b>NO</b>	<b>DESCRIPTION</b>	<b>Q'TY</b>
1	Left handle	1	27	Central Shaft	1
2	Left housing	1	28	Gear	1
3	Spring	1	29	Driving spindle	1
4	Switch lock button	1	30	Press plate	1
5	Switch	1	31	Roller	1
6	Wire (black)	1	32	Gear case cover	1
7	Terminal	1	33	Screw	6
8	Wire (red)	1	34	Bearing press plate	1
9	Inductor (red wire)	1	35	Oil bearing	1
10	Inductor (black wire)	1	36	Reciprocating shaft assembly	1
11	Circlip	1	37	Oil bearing	1
12	Capacitor	2	38	Saw blade	1
13	Motor	1	39	Support plate	1
14	Transfer shaft	1	40	Reed	1
15	Screw	3	41	Pressure plate	1
16	Connection block	1	42	Washer	1
17	Screw	2	43	Screw	1
18	Circlip	1	44	Circlip	1
19	Pinion	1	45	Right housing	1
20	Bearing 6000	1	46	Lock-on lever	1
21	Circlip	1	47	Screw	2
22	Gear case	1	48	Screw	17
23	Bearing 608	1	49	Right handle	1
24	Circlip	1	50	Battery pack	1
25	Bearing 6000	1	51	charger	1
26	Washer	1			1