


EXPLOSIVE VIEW OF WD041310180



PART LIST OF WD041310180

NO	DESCRIPTION	Q'TY	NO	DESCRIPTION	Q'TY
1	Screw	13	29	Gear	1
2	Right housing	1	30	Thrust needle bearing	1
3	Pinion	1	31	Rocker bearing	1
4	Shaft sleeve	1	32	Tower Spring	1
5	Seal sleeve	1	33	Clutch	1
6	Screw	1	34	Adjustable positioning block	1
7	Motor	1	35	Bearing	1
8	Dust cover	1	36	Washer	1
9	Circlip	1	37	Middle Axle	1
10	Bearing	1	38	Tower Spring	1
11	Oil seal	1	39	Washer	1
12	Rotary sleeve	1	40	Washer	1
13	Steel Ball	1	41	Fastening sleeve	1
14	Steel Ball	4	42	Retaining Ring	1
15	Gear	1	43	Protective cap	1
16	Retaining Ring	1	44	Magnet ring	1
17	Needle Bearing	1	45	Rotation control lever	1
18	O ring	1	46	Switch	1
19	Impact hammer	1	47	Sealing strip right	1
20	Damping bushing	1	48	Sealing strip left	1
21	O ring	1	49	Circlip	1
22	Retaining ring	1	50	Terminal	1
23	Piston	1	51	Left housing	1
24	O ring	1	52	O ring	1
25	Cylinder	1	53	Mode selection knob	1
26	Cylinder pin	1	54	Battery pack	1
27	Washer	2	55	Charger	1
28	Needle bearing	1			