


450W ASPIRATOR BLOWER EXPLOSIVE VIEW



450W ASPIRATOR BLOWER PART LIST

NO	DESCRIPTION	Q'TY	NO	DESCRIPTION	Q'TY
1	Nozzle	1	15	Handle cover	1
2	Locating ring	1	16	Switch	1
3	Left air blower housing	1	17	Screw	2
4	Screw	8	18	Cover	1
5	Nut	1	19	Motor housing	1
6	Fan	1	20	Label	1
7	Right air blower housing	1	21	Brush holder	2
8	Screw	4	22	Carbon brush	2
9	Washer	1	23	Brush holder cap	2
10	Bearing	1	24	Cable and plug	1
11	Rotor	1	25	Cable protector	1
12	Screw	2	26	Screw	2
13	Bearing	1	27	Cable clamp	1
14	Stator	1	28	Dust bag	1