

PART LIST OF WD030610254

NO	DESCRIPTION	Q'TY	NO	DESCRIPTION	Q'TY
1	Hex bolt	2	41	Hex socket head bolt	2
2	Footrest	1	42	Screw	1
3	Stiffening plate	2	43	Cotter	1
4	Clamping pad	1	44	Box cover	1
5	Wheel	2	45	Lock nut	2
6	Washer	4	46	Overload protector	1
7	Lock nut	4	47	Wire box	1
8	Connecting plate	2	48	Base plate	1
9	Butterfly nut	3	49	Chassis	1
10	Support	1	50	Handle	1
11	Blanking plate	2	51	Lock nut	3
12	Washer	6	52	Screw	2
13	Lock nut	5	53	Soft handle	1
14	Support bolt	1	54	Body	1
15	Wave washer	2	55	Screw	8
16	Screw	2	56	Washer	4
17	Balance bar	1	57	Screw	4
18	Hex bolt	2	58	Main label	1
19	Support block	2	59	Switch	1
20	Washer	2	60	Tapping screw	10
21	Anti-slip foot sleeve	2	61	Pointer	1
22	Support frame	1	62	Washer	12
23	Locking knob	2	63	Screw	19
24	Lock nut	9	64	Washer	1
25	Washer	23	65	Washer	1
26	Hex bolt	2	66	Washer	1
27	Support	1	67	Rod	1
28	Knob	1	68	Handle	1
29	Washer	2	69	Screw	2
30	Washer	1	70	Hand wheel	1
31	Hex socket head bolt	3	71	Knob	1
32	Washer	4	72	Screw	1
33	Stop block	2	73	Washer	2
34	Side plate	1	74	Forcing spindle	1
35	Angle iron	1	75	Handle	1
36	Screw	1	76	Stop block	2
37	Limit parts	1	77	Screw	2
38	Spring	1	78	Fixed seat	1
39	Hex nut	1	79	Push sticker	1
40	Knob	1	80	Pointer	1

81	Screw	1	123	Cover	1
82	Spring washer	21	124	Stopper	1
83	Hex socket head bolt	6	125	Step bolt	2
84	Guide ruler	1	126	Guide tube	1
85	Hex socket head screw	1	127	Left extension table	1
86	Clip	1	128	Extension rod	2
87	Locking plate	1	129	Screw	4
88	Fixed board	1	130	Table insert	1
89	Tapping screw	2	131	Extension rod	2
90	Pin	1	132	Rear extension table	1
91	Knob	1	133	Right extension table	1
92	Pin	1	134	Extension rod	2
93	Pin	1	135	Knob	6
94	Thread rod	1	136	Label	1
95	Spanner	2	137	Main worktable	1
96			138	Blanking plate	3
97	Support seat	1	139	Label	1
98	Guide tube	1	140	Move baffle	1
99	Hex bolt	1	141	Fixed seat	2
100	Washer	1	142	Screw	6
101	Spring	1	143	Ruler seat	1
102	Press plate	1	144	Main label	1
103	Friction pad	1	145	Label	1
104	Cable cleat	2	146	Left guard	1
105	Protective ring	1	147		
106	Cable cleat	1	148	Upper cover	1
107	Cable and plug	1	149	Electrode	1
108	Seat	2	150	Laser switch	1
109	Snap gauge	1	151	Battery	2
110	Hex socket head bolt	4	152	Laser	1
111	Fixed seat of guide plate	1	153	Electrode	1
112	Blanking plate	3	154	Screw	2
113	Label post	1	155	Cover	1
114	Label	1	156	Support seat	1
115	Hex bolt	7	157	Rive knife	1
116	Hex socket head bolt	4	158	Cotter	1
117	Tapping screw	7	159	Press plate	1
118	Guide bar	1	160	Knob	1
119	Pointer	1	161	Right guard	1
120	Knob	2	162	Pin	1
121	Angle support	1	163	Spring	1
122	Knob	1	164	Side guard	1

165	Washer	2	187	Washer	10
166	Knob	1	188	Spring washer	10
167	Tapping screw	2	189	Blade guard	1
168			190	Adjust rod	1
169	Spring washer	1	191	Adjust seat	1
170	Baffle	1	192	Flat key	1
171	Nut	1	193	Angle gear	1
172	Outer flange	1	194	Retainer ring	1
173	Blade	1	195	Adjust rod	1
174	Inner flange	1	196	Screw	2
175	Dust exit	1	197	Variable diameter circle	1
176	Screw	2	198	Foot rest	1
177	Washer	1	199	Washer	1
178	Safety baffle	1	200	Sleeve	2
179	Screw	4	201	Clip	1
180	Fixed block	2	202	Washer	2
181	Sliding block	2	203	Three-wave circle	1
182	Body	1	204	Capacitor	1
183	Cover plate	1	205	Hex socket head bolt	1
184	Round pin	2	206	Tapping screw	3
185	Motor	1	207	Hex key	1
186	Guide post	2			