


EXPLOSIVE VIEW OF WD041210210



PART LIST OF WD041210210

NO	DESCRIPTION	Q'TY	NO	DESCRIPTION	Q'TY
1	Bolt	1	29	Bearing 6900	1
2	Outer flange	1	30	Rotor	1
3	Saw blade	1	31	Bearing 607	1
4	Inner flange	1	32	Stator	1
5	Circlip	1	33	Housing	1
6	Screw	6	34	Screw	5
7	Moving guard lever	1	35	Locking bolt	1
8	Moving guard	1	36	Spring	1
9	Screw	1	37	Locking knob	2
10	Bumper	1	38	Washer	2
11	Extension Spring	1	39	Bolt	1
12	Screw	1	40	Base plate	1
13	Fixed guard	1	41	Left handle	1
14	Nut	1	42	Screw	1
15	Screw	4	43	Lock-off button	1
16	Spindle	1	44	Spring	1
17	Cover of gear housing	1	45	Switch	1
18	Bearing 6901	2	46	Locking bolt	1
19	Circlip	1	47	Right handle	1
20	Distance sleeve	1	48	Screw	5
21	Gear	1	49	Switch trigger	1
22	Bearing HK0608	1	50	Spring	1
23	Gear housing	1	51	PCB	1
24	Spring	1	52	Terminal	1
25	O-ring	1	53	Battery pack	1
26	Spindle lock	1	54	Charger	1
27	Screw	2	55	Parallel guide	1
28	Fan baffle	1	56	Allen-key	1