


EXPLOSIVE VIEW OF WD041310210



PART LIST OF WD041310210

NO	DESCRIPTION	Q'TY	NO	DESCRIPTION	Q'TY
1	Protective cap	1	42	Guide rod	1
2	Retaining ring	1	43	Spring	1
3	Fastening sleeve	1	44	Shaft plate	1
4	Washer	1	45	Bearing HK0810	3
5	Steel ball positioning seat	1	46	Retaining ring	1
6	Thrust ring	1	47	Pinion	1
7	Steel ball	1	48	Switch element	1
8	Washer	1	49	Intermediate shaft	1
9	Spring	1	50	Coupling hub	1
10	Mechanical seal	1	51	Switch element	1
11	Bushing	1	52	Rocker bearing	1
12	Bearing 61805	1	53	Gear	1
13	Retaining ring	2	54	Aluminum bracket	1
14	Washer	1	55	Holding plate	1
15	Spring	1	56	Seal ring	1
16	Big gear	1	57	O-ring	1
17	Ratchet disk	1	58	Wool block	1
18	Straight pin	2	59	Oil guide ring	1
19	Rotary sleeve	1	60	Bearing 609	1
20	Gear housing	1	61	Rotor	1
21	O-ring	2	62	Bearing 607	1
22	Thrust ring	1	63	Stator	1
23	Striker pin	1	64	Screw	9
24	Guide bushing	1	65	Right housing	1
25	O-ring	1	66	Switch	1
26	Holding jacket	1	67	Rotational direction switch	1
27	Retaining ring	1	68	Left housing	1
28	Striker	1	69	Screw	4
29	O-ring	1	70	Battery pack	1
30	Hammer piston	1	71	Terminal	1
31	Washer	2	72	LED light cover	1
32	Piston pin	1	73	Rubber pin	2
33	Bushing	1	74	PCB	1
34	Driver pin	1	75	Clamping band	1
35	O-ring	1	76	Clamping bolt	1
36	Mode selector knob	1	77	Clamping holder	1
37	Spring	1	78	Depth gauge	1
38	Release button	1	79	Spring	1
39	Shifting fork	1	80	Button for depth gauge adjustment	1
40	Spring	1	81	Auxiliary handle	1
41	Shaft plate	1	82	Charger	1